



Door Heights & Handle Positions

Door handle heights are now positioned according to some 'rules' set up with the move to Yale locks. The purpose is to ensure consistency and repeatability in case a remake is ever required.

Long leg sizes

Handle positions rules	
Single door	
Standard handle	High handle
From 1617 to 2142 : Handle in center of sash	From 1617 to 2090 : Handle at 690 from top of sash
From 2143 to 2240 : Handle at 1071 from the bottom	From 2091 to 2240 : Handle at 1400 from bottom of sash

Long leg sizes

Handle positions rules
Double door
Standard handle
From 1720 to 2142 : handle in center of sash
from 2143 to 2240 : handle at 1071 from the bottom

Long leg sizes

Cylinder positions rules
Auto-engage / Townhouse lock
From 1723 to 1920 : Cylinder at 600 from top of sash
From 1921 to 2240 : Cylinder at 1316 from bottom of sash